Nokia 6310i SIM card Replacement

This guide shows how to remove the sim card.

Written By: Mustafa



TOOLS:

- Fingers (1)

Step 1 — Battery






- Press and hold the battery release button and slide the battery away from the Nokia logo

Step 2 — SIM card







- Slide the SIM card lock away from the SIM card.
- ⓘ The SIM card pops out. Remove the SIM card.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-11-06 12:08:40 AM.